

1. Put the drawer under the worksurface and pull out the drawer
2. Screw the box to the worksurface

