

Fellowes

809146/809145

100091614/100098871

SmartView single monitor arm - Black/White







Features & Specifications



17"-32"

6.60-19.80lbs (3-9kg)



CAUTION:
DO NOT exceed maximum listed weight capacity.
Serious injury or property damage may occur.



Alternative Placements




CAUTION:
DO NOT rotate monitor past rear edge of desk. Doing so will create an unstable situation and may cause equipment damage or personal injury.



Components

1

Desk Clamp





Dynamic Arm (1)



Single Base Mount (1)



VESA Plate (1)



Monitor Screw (4)
M5x12mm



Monitor Screw (4)
M4x12mm




Monitor Screw Washer (4)
D5



2-in-1 Allen Key (1)
4/5mm




Allen Key (1)
2.5mm



⚠ Do not overtighten the screw.


2

Arm Installation




3

Display Installation



4


Cable Management

**IMPORTANT:**

Ensure you have allowed free cable for monitor rotation.

5


Adjustment Step

**WARNING & IMPORTANT:**

Raise the arm to the uppermost position before removing monitor, it may spring up when unloaded, that may result in personal injury or property damage.

USEFUL TIP:

Adjustment will be easier and more precise if the top motion arm is horizontally positioned as shown.

**Clockwise(+)**


Increase lift strength if the monitor does not stay up when raised.

Counter-Clockwise(-)

Decrease lift strength if the monitor does not stay down when lowered.


**CAUTION:**

DO NOT overtighten screw as it may damage to your equipment, screw head or threads.




6

Adjustment Step



CAUTION:
DO NOT remove screw as it may bring damage or function loss.
DO NOT overtighten screw as it may damage to screw head or threads.



You made it, ready for however you make best.

